

RADIAN® AFTERBURNER™ + RAMJET™

▷ MICRO-COMPENSATOR + PISTOL BARREL

INSTRUCTIONS

INSTALLATION | Remove the magazine, visually inspect the chamber to ensure the pistol is clear. Remove slide from frame per original manufacturer's instructions. Remove recoil spring assembly and existing barrel. Add light coating of oil to Radian® RAMJET™ barrel exterior and barrel hood. Install RAMJET™ into slide and reinstall recoil spring. Slide AFTERBURNER™ micro-compensator over the RAMJET™ barrel, tighten tapered screw to 15 in.-lb. Reinstall the assembled slide onto frame. Test function to complete installation.

CLEANING | The inside of the RAMJET™ barrel bore should be cleaned just like any other pistol barrel, using a cleaning patch or bore snake. If you anticipate a high round count, we suggest coating the barrel-to-compensator interface before installing the AFTERBURNER™ on the RAMJET™ with heat-resistant gun oil to prevent carbon lock. If the AFTERBURNER™ becomes carbon locked to the barrel, submerge the AFTERBURNER™ and RAMJET™ in gun oil/CLP overnight and spin compensator to break free.



@RADIANWEAPONS

CONTACT US

E SUPPORT@RADIANWEAPONS.COM
O 503.893.2987

875 NE KINGWOOD AVE
REDMOND, OR | 97756